

---




**INSTALLATION INSTRUCTIONS**  
Downlight Lighting\_299Lighting

**SEGURA**  
**RECESSED**  
**TRIM**


# SEGURA TRIM

## INSTALLATION INSTRUCTIONS


Downlight\_299Lighting




<b>56-AH1-F10-8**-*0-C</b>	L = 266mm
<b>56-A*1-F20-8**-**-C</b>	L = 384mm
<b>56-A*1-F35-8**-**-C</b>	L = 464mm
<b>56-A*1-F81-8**-**-C</b>	L = 664mm




1.






3.



4.




2.




# SEGURA TRIM

## INSTALLATION INSTRUCTIONS


Downlight\_299Lighting




5.




6.




7.



8.




9.



- The manufacturer is not responsible for the incorrect use and assembly of its products
- The installation may only be carried by authorised specialist
- Always switch-off the power supply before carrying out any maintenance









# SEGURA TRIM

## INSTALLATION INSTRUCTIONS

Downlight\_299Lighting


<b>56-A*1-F13-8**-**-C</b>	L = 964mm
<b>56-AH1-F24-8**-**-C</b>	L = 1264mm




# SEGURA TRIM

## INSTALLATION INSTRUCTIONS


Downlight\_299Lighting




5.




6.



7.




8.




9.

a)



b)



- The manufacturer is not responsible for the incorrect use and assembly of its products  
 - The installation may only be carried by authorised specialist  
 - Always switch-off the power supply before carrying out any maintenance

